



PIGMENTOS METÁLICOS
METALLIC PIGMENTS

PIGMENTOS DE ALUMINIO Y BRONCE
ALUMINUM AND BRONZE PIGMENTS

Cosméticos
Cosmetics

Together creating
a brilliant world

OFICINAS CORPORATIVAS

Azahares No. 26 Desp. 203
Col. Santa María Insurgentes
C.P.: 06430, México D.F.
Tel: (52)-(55) 1946.0850
5583.0557
mail: info@metapol.com.mx

HEADQUARTERS

Azahares No. 26 Desp. 203
Col. Santa María Insurgentes
Z.C.: 06430, México D.F.
Ph: (52)-(55) 1946.0850
5583.0557
mail: info@metapol.com.mx

PLANTA

Carretera a Veracruz Km.144
San Cosme Xaloztoc
Tlaxcala, México
C.P.: 90460
Tel: (241) 413.0126
Fax: (241) 413.0156

PLANT

Carretera a Veracruz Km.144
San Cosme Xaloztoc
Tlaxcala, México
Z.C.: 90460
Ph: (241) 413.0126
Fax: (241) 413.0156



metapol.com.mx





METALLIC PIGMENTS FOR COSMETICS

PRODUCTS

SiO LINE

PRODUCT	TYPE	FORM	D-50	%NV	L/NL
SiO D3600	Encapsulated powder	Dollar	36	100%	NL
SiO D5500	Encapsulated powder	Dollar	55	100%	NL
SiO D6000	Encapsulated powder	Dollar	60	100%	NL
SiO F2000	Encapsulated powder	Irregular	20	100%	NL

BRIO LINE

PRODUCT	TYPE	FORM	D-50	%NV	L/NL
*U 5000	Encapsulated powder	Irregular	50	100%	NL
*B 4500	Encapsulated powder	Irregular	45	100%	NL
*R 2800	Encapsulated powder	Irregular	28	100%	NL
*R 1800	Encapsulated powder	Irregular	18	100%	NL
*I 1400	Encapsulated powder	Irregular	14	100%	NL

**U available in: Rich Gold, Pale Gold, Rich Pale Gold, Copper and English Green*

**B available in: Mandarine*

**R available in: Rich Gold and Pale Gold*

**I available in: Rich Gold and Pale Gold*

ALU LINE

PRODUCT	TYPE	FORM	D-50	%NV	L/NL
ALU D10015 IPA	Paste	Dollar	15	70%	NL
ALU V4011 L	Suspension	VMP	11	10%	L



- Always use fresh batches; expired products may generate agglomeration, though modifying the particle distribution.
- Addition of metallic pigment ranges from 0.1-20% depending on the desired effect.

NOTES

* Prior to use and application of this product, consult the technical data sheet to consider other technical requirements and safety precautions.

*The information provided corresponds to the current technology, knowledge and experience. All the indications are given as guiding information and / or advice, so that METAPOL, S.A. DE C.V., disclaims any liability for its misuse.

RECOMMENDED APPLICATIONS

Following recommendations should be observed in order to obtain the best performance out of the aluminum and bronze pigments in cosmetics:

- Pre-moistening in the system to be applied, helps with molecules separation. (Recommendation at a ratio of 1:1 or 1:2 of pigment and system).
- Stirring should be made with propeller or disk agitators; serrated or bladed stirrers generate shear stress damaging the metallic particles.
- Stir at low speeds; not above 400 rpm.

